Centistokes Fuel Dilution Chart

0	60	80	100	120	140	160	180	200	220	240	260	280	300	320	340
1	58	77	95	114	133	152	170	189	208	226	245	263	281	300	318
2	56	74	91	109	126	144	161	179	196	213	230	247	264	281	298
3	54	71	87	104	120	137	153	169	185	201	217	232	248	264	279
4	52	68	83	99	114	130	145	160	174	189	204	218	233	248	262
5	50	65	80	94	109	123	137	151	165	178	192	205	219	232	245
6	48	62	76	90	104	117	130	143	156	168	181	193	206	218	230
7	46	60	73	86	99	111	123	135	147	159	171	182	194	205	216
8	45	58	70	82	94	106	117	128	139	150	161	172	182	193	203
9	43	55	67	78	90	100	111	121	132	142	152	162	172	181	191
10	42	53	64	75	85	95	105	115	125	134	143	153	162	170	179
11	40	51	61	72	81	91	100	109	118	127	135	144	153	161	169
12	39	49	59	69	78	86	95	104	112	120	128	136	144	151	159
13	37	47	56	66	74	82	90	98	106	114	121	128	136	142	150
14	36	45	54	63	71	78	86	93	101	108	114	121	128	134	141
15	35	44	52	60	67	75	82	89	95	102	108	115	121	127	133

Locate your oil's initial viscosity on the upper row then move down the column until you find your oil's current viscosity. Reading the fuel dilution percent on the left side will approximate the percentage of #2 diesel fuel contained in your oil sample.

Please be aware that several other factors could lower oil viscosity including oil breakdown and mixing oils. Contact us at Visgage.com for more information.

